

Spare part	Spare part description	Contained in
RA07	Bushing for ZX41 foundation box	ZX41
RA10	Washer with mechanical stop for ZX41	ZX41

